

5.2.2 Lab: Select and Install a Network Adapter

Candidate: Deepa Ponnusamy ()

Time Spent: 29:28

Score: 100%



Task Summary

Required Actions

- ✓ Install the 1000BaseTX network adapter on the Exec workstation
- ✓ Connect the Exec workstation to the network through the new NIC
- ✓ Verify that the Exec workstation can communicate with the internet using the new NIC [Show Details](#)

Explanation

Complete this lab as follows:

1. Insert the PCI adapter into the motherboard.
 - a. Switch to the **Motherboard** view of the computer.
 - b. In the Inventory, expand **GPUs/Expansion Cards**.
 - c. Drag the brown **Network Adapter, Ethernet 10/100/1000BaseTX, PCIe** card to a free blue PCIe slot on the computer's motherboard.
2. Move the Ethernet cable from the computer's built-in network adapter to the new PCIe network card.
 - a. Above the computer, select **Back** to switch to the back view of the computer.
 - b. Drag the **Ethernet cable** from the built-in port to the port on the PCIe network adapter.
3. Confirm that the computer is connected to the local network and the internet.
 - a. Switch to the **Front** view of the computer.
 - b. Select the **power button** on the computer case to turn on the computer.
Wait for the operating system to load.
 - c. Right-click **Start** and then select **Terminal (Admin)**.
 - d. From the PowerShell prompt, type **ping 192.168.0.10** and then press **Enter** to test connectivity to the local network server.
 - e. From the PowerShell prompt, type **ping 198.28.2.254** and then press **Enter** to test connectivity to the internet.